

Superior Mark®

Recommended installation steps

Quick Guide

- STEP 1** Remove loose debris.
- STEP 2** Scrape away paint and adhesive residue.
- STEP 3** Scrub surface using a floor degreaser and rinse with water.
- STEP 4** Use denatured alcohol to prepare surface.
- STEP 5** Wait until installation is completely dry.
- STEP 6** Take measurements and mark installation lines.
- STEP 7** Install Superior Mark floor tape.
- STEP 8** Trim tape using set square and safety knife.
- STEP 9** Firmly tamp the tape to the floor surface at least three times in the same direction in which it was initially applied.
- STEP 10** Enjoy your new floor marking!

CLEAN



MARK



APPLY



TAMP

